



MAGNETIC REED DOOR & WINDOW SWITCH

Detect unauthorized entry or intrusion

The magnetic reed switch may be used with all Sensaphone models to detect any unauthorized entry or intrusion. They are usually installed on doors and windows to detect their opening and closing. Several magnetic reed switches may be wired in series.



TECH SPECS

Name	Magnetic Reed Door & Window Switch
Connection	Hardwired
Housing	Plastic
Dimensions	2.5 x .75 x .5" 63 x 19 x 13mm
Sensor Series	Contact Series

All specifications subject to change without notice

Product Name

Part Number

Contact Type Magnetic Reed Door & Window SwitchFGD-0006



Family owned and made in the USA since 1985

901 Tryens Road

Phone: 877-373-2700

Aston, PA 19301

Web: sensaphone.com

